GUARDIAN



PRE-START UP CHECK FOR DRIVERS

Before you start each trip, it pays to check that your Guardian system is working correctly to protect you while driving.

Gen 1 pre-start up checks

- 1 Check that the LED light under the driver facing camera goes out after pre-system checks.
- **2** At night there should be a dull glow from IR pods
- **3** There should be a light on the forward-facing camera to indicate it is working



IR pods



LED light